

Marca	Modelo
Acer	Z130
Acer	Z150
Acer	Z410 Liquid
Acer	Z520 Liquid
AEG	S200
Alcatel	156
Alcatel	552
Alcatel	557
Alcatel	292A
Alcatel	4010A
Alcatel	5010G^PIXI4-5 3G_1.0
Alcatel	5036A ONE TOUCH
Alcatel	5045G^PIXI4-5 4G
Alcatel	700A
Alcatel	7047A ^One Touch Pop C9
Alcatel	7048A^GO PLAY
Alcatel	8050E^PIXI4 6 3G
Alcatel	C635
Alcatel	C651
Alcatel	C652
Alcatel	C700A
Alcatel	C701A
Alcatel	E159
Alcatel	E225
Alcatel	E227
Alcatel	E256
Alcatel	E801
Alcatel	ELLE
Alcatel	OT 1035A Ginger2
Alcatel	OT-1030A Ginger
Alcatel	OT-1045G
Alcatel	OT-1052
Alcatel	OT-2004C Tango 2+
Alcatel	OT-209A
Alcatel	OT-255A
Alcatel	OT-282A
Alcatel	OT-3041G
Alcatel	OT-305A
Alcatel	OT-363A
Alcatel	OT-385JA
Alcatel	OT-4007A Pixi
Alcatel	OT-4009A Pixi 3 3.5
Alcatel	OT-4013M Pixi 3
Alcatel	OT-4018A
Alcatel	OT-4027A^PIXI3-4.5
Alcatel	OT-4034G ^PIXI4-4 3G

Marca	Modelo
Alcatel	OT-5015A Pop3-5 3G
Alcatel	OT-5036F Pop C5
Alcatel	OT-6016A IDOL 2 MINI
Alcatel	OT-602A
Alcatel	OT-6036A ^ Idol 2 Mini
Alcatel	OT-6039A^IDOL3 4.7
Alcatel	OT-6040A
Alcatel	OT-6045B Idol3 5.5
Alcatel	OT-639G
Alcatel	OT-7040A POP C7
Alcatel	OT-7055A Hero 2c
Alcatel	OT-706A
Alcatel	OT-708A
Alcatel	OT-710A
Alcatel	OT-720
Alcatel	OT-800A
Alcatel	OT-808
Alcatel	OT-813
Alcatel	OT-880
Alcatel	OT-918A
Alcatel	OT-980A
Alcatel	OT-990A
Alcatel	OT-C700
Alcatel	OT-S211A
Alcatel	OT-S521A
Alcatel	OT-V770A
Alcatel	OT-Y200 Gate II
Apple	A1687 ^iPhone 6S Plus
Apple	A1688 ^iPhone 6S
Apple	A1723 ^iPhone SE
Apple	iPhone
Apple	iPhone 3G
Apple	iPhone 3GS
Apple	iPhone 4
Apple	iPhone 4S
Apple	iPhone 5
Apple	iPhone 5c
Apple	iPhone 5s
Apple	iPhone 6
Apple	iPhone 6 Plus
ASK	TV8010 TV analoga
Avvio	505
BESTEL	N99i TV analoga
BESTEL	X300 TV analoga
BlackBerry	6280
BlackBerry	7100

Marca	Modelo
BlackBerry	7130
BlackBerry	7290
BlackBerry	8100
BlackBerry	8120
BlackBerry	8300
BlackBerry	8320
BlackBerry	8520
BlackBerry	8700
BlackBerry	8800
BlackBerry	8900
BlackBerry	9000
BlackBerry	9100
BlackBerry	9300
BlackBerry	9320
BlackBerry	9360
BlackBerry	9380
BlackBerry	9500
BlackBerry	9520
BlackBerry	9530
BlackBerry	9550
BlackBerry	9630
BlackBerry	9700
BlackBerry	9720
BlackBerry	9780
BlackBerry	9790
BlackBerry	9800
BlackBerry	9810
BlackBerry	9860
BlackBerry	9900
BlackBerry	Q10
BlackBerry	Q5
BlackBerry	Z10
BlackBerry	Z30
CAT	B10
Doro	PhoneEasy 345 GSM
Doro	PhoneEasy 410 GSM
Ericsson	CA-638
Ericsson	CF-388
Ericsson	CF-688
Ericsson	CF-768
Ericsson	CH-388
Ericsson	P7389
Ericsson	R-380
Ericsson	R520
Ericsson	R520m
Ericsson	T18Z

Marca	Modelo
Ericsson	T28s
Ericsson	T28W
Ericsson	T39m
Ericsson	T66m
Ericsson	W35
FireFly	F-100
HP	iPaq 6945
HTC	Desire 500
HTC	Desire A
HTC	EXPLORER
HTC	HD2
HTC	Magic
HTC	ONE
HTC	ONE M8
HTC	ONE M9
HTC	ONE X
HTC	P3700 ^ Touch Diamond
HTC	P5520 ^ Touch Dual
HTC	PB74120 ^ TOUCH 2
HTC	S730
HTC	Sensation
HTC	T8585 ^ HD2
HTC	T-Mobile G1
HTC	Touch Viva
HTC	Wildfire
Huawei	ALE-L21 ^ P8 LITE
Huawei	ALE-L23 ^ P8 LITE LTE
Huawei	CHC-U03 ^ G PLAY Mini
Huawei	G5000
Huawei	G510
Huawei	G5521
Huawei	G6006
Huawei	G6151
Huawei	G7005
Huawei	G7010
Huawei	G7206
Huawei	G7210
Huawei	G7220
Huawei	G7300
Huawei	G730-U251
Huawei	G735-L03 ^ Honor 4X
Huawei	GRA-L09 ^P8
Huawei	KII-L33^GR5
Huawei	MT7-L09 ^ MATE 7
Huawei	NXT-L09^MATE 8
Huawei	P6

Marca	Modelo
Huawei	U526
Huawei	U8150
Huawei	U8180
Huawei	U8185-5
Huawei	U8800
Huawei	U9120
Huawei	U9200
Huawei	Y210
Huawei	Y220-U05
Huawei	Y330-U05 ^ Y330
Huawei	Y360-U23 ^ Y360
Huawei	Y520-U03 ^ Y520
Huawei	Y600-U151 ^ Ascend Y600
Huawei	Y625-U13 ^ Y625
Huawei	Y635-L02
Huawei	Y635-L03
iMate	JAM
JZH-MOBILE	L700
Karbons	A5s ^
Karbons	Titanium S8 ^ S8
Kioto	A10
Kioto	A17
Kioto	A9 ^ 3G Smart Phone
Kioto	E1 ^ E1 Bar-Phone
Kioto	E20
Lenovo	A319
Lenovo	A6000-I
Lenovo	A680
Lenovo	A706
Lenovo	K900
Lenovo	S820
LG	A130
LG	A133
LG	A180
LG	A270
LG	C1300
LG	C195
LG	C365
LG	C660 ^ Optimus Pro
LG	D100j ^ L20
LG	D160J ^ L40
LG	D213cj ^ Optimus L50
LG	D290J ^ L 70+
LG	D320 ^ L70
LG	D625 ^ G2 Mini LTE
LG	D722PA ^ G3 Beat LTE

Marca	Modelo
LG	D805 ^ OPTIMUS G2
LG	D855 ^ G3
LG	D956 ^ Flex
LG	E400g L3
LG	E425j L3 II
LG	E450j L5 II
LG	E510g ^ Optimus Live
LG	E612g L5
LG	E900 ^ Optimus 7
LG	E960 ^ Nexus 4
LG	G2 Mini dual SIM
LG	G4015
LG	GB280
LG	GD510
LG	GD880
LG	GM360
LG	GM600
LG	GS107
LG	GS155
LG	GS290
LG	GT350i
LG	GU230
LG	GW620
LG	H326G ^ LEON 3G
LG	H502G MAGNA 3G
LG	H520G ^ MAGNA LTE
LG	H540 ^ G4 Stylus
LG	H635C ^ G4 Stylus LTE
LG	H815P G4
LG	K430T ^K10 LTE
LG	KC910Qa
LG	KE970
LG	KE990
LG	KF755
LG	KM335
LG	KM900
LG	KP105
LG	KP115
LG	KP150q
LG	KP265d
LG	KP330
LG	KP502
LG	KS500
LG	KU990
LG	ME550
LG	ME770

Marca	Modelo
LG	MG101
LG	MG105
LG	MG110
LG	MG120
LG	MG165
LG	P350 Optimus Me
LG	P500 ^ Optimus One
LG	P708g L7
LG	P712
LG	P713 ^ L7 II
LG	P768 L9
LG	P880 ^ Optimus 4x
LG	P920h ^ Optimus 3D
LG	P990 ^ Optimus 2x
LG	T300
LG	T310i
LG	T325
LG	T395
LG	X170g ^Prime II
Microsoft	535 ^ LUMIA 535
Microsoft	640 LTE ^ Lumia 640 LTE
Microsoft	640XL ^ LUMIA 640XL 3G
Microsoft	RM-1070 ^ Lumia 435
Motorola	A3100
Motorola	C115
Motorola	C118
Motorola	C236
Motorola	C261
Motorola	C350
Motorola	C650
Motorola	EM28
Motorola	EM35
Motorola	EX225
Motorola	FX2000
Motorola	KRZR K1
Motorola	L6
Motorola	MB525
Motorola	MB632 ^ Pro+
Motorola	MB860 ^ Atrix
Motorola	MotoQ GSM
Motorola	ROCKR E1
Motorola	Rokr E8
Motorola	U6
Motorola	V172
Motorola	V180
Motorola	V191

Marca	Modelo
Motorola	V3
Motorola	V3i
Motorola	V555
Motorola	V8
Motorola	V9 ^ Ferrari
Motorola	W220
Motorola	W230
Motorola	W270
Motorola	W375
Motorola	W396
Motorola	WX295
Motorola	XT1032 Moto G
Motorola	XT1033 ^ Moto G 2014
Motorola	XT1040 Moto G LTE
Motorola	XT1063 ^ Moto G 2014
Motorola	XT1072 ^Moto G 2da gen 4G
Motorola	XT1505 Moto E
Motorola	XT1542 ^ Moto G 3ra Gen
Motorola	XT1563 ^ Moto X Play
Motorola	XT303 ^ Silver Smart
Motorola	XT320 ^ Defy Mini
Motorola	XT531 ^ Fire XT
Motorola	XT910 ^ Razr
Motorola	XT914 ^ Razr D1
Motorola	XT919 ^ Razr D3
Motorola	Z6
Motorola	zte
Neuimage	NIM-400^
NOKIA	106
NOKIA	111
NOKIA	201
NOKIA	205
NOKIA	208
NOKIA	210
NOKIA	220
NOKIA	230
NOKIA	300
NOKIA	302
NOKIA	303
NOKIA	306
NOKIA	311
NOKIA	500
NOKIA	501
NOKIA	808
NOKIA	1100
NOKIA	1110

Marca	Modelo
NOKIA	1112
NOKIA	1200
NOKIA	1208
NOKIA	1600
NOKIA	1616
NOKIA	1661
NOKIA	2330
NOKIA	2600
NOKIA	2610
NOKIA	2630
NOKIA	2650
NOKIA	2660
NOKIA	2690
NOKIA	2730
NOKIA	2760
NOKIA	3120
NOKIA	3200
NOKIA	3220
NOKIA	3300
NOKIA	3500
NOKIA	3555
NOKIA	3595
NOKIA	3600
NOKIA	3620
NOKIA	5070
NOKIA	5130
NOKIA	5190
NOKIA	5200
NOKIA	5220
NOKIA	5230
NOKIA	5233
NOKIA	5300
NOKIA	5310
NOKIA	5530
NOKIA	5610
NOKIA	5800
NOKIA	6010
NOKIA	6020
NOKIA	6061
NOKIA	6070
NOKIA	6101
NOKIA	6103
NOKIA	6125
NOKIA	6126
NOKIA	6131
NOKIA	6170

Marca	Modelo
NOKIA	6210
NOKIA	6230
NOKIA	6300
NOKIA	6303
NOKIA	6670
NOKIA	6680
NOKIA	6681
NOKIA	6682
NOKIA	6700
NOKIA	6800
NOKIA	6822
NOKIA	7020
NOKIA	7230
NOKIA	7310
NOKIA	7360
NOKIA	7373
NOKIA	7610
NOKIA	7710
NOKIA	100 1
NOKIA	2220s-b
NOKIA	2700c
NOKIA	2720a
NOKIA	3600 slide
NOKIA	5130c-2
NOKIA	5235-1b
NOKIA	C1-01
NOKIA	C2-01
NOKIA	C2-02
NOKIA	C3-00
NOKIA	C5-03
NOKIA	C6-00
NOKIA	C6-01
NOKIA	C7-00
NOKIA	E5-00 2
NOKIA	E62
NOKIA	E63
NOKIA	E65
NOKIA	E7-00
NOKIA	E72
NOKIA	E75
NOKIA	Lumia 1320
NOKIA	Lumia 510
NOKIA	Lumia 520
NOKIA	Lumia 610
NOKIA	Lumia 620
NOKIA	Lumia 625

Marca	Modelo
NOKIA	Lumia 630
NOKIA	Lumia 635
NOKIA	Lumia 710
NOKIA	Lumia 720
NOKIA	Lumia 800
NOKIA	Lumia 900
NOKIA	Lumia 920
NOKIA	Lumia 925
NOKIA	N73
NOKIA	N75-3
NOKIA	N78
NOKIA	N8-00
NOKIA	N81
NOKIA	N85
NOKIA	N91-2
NOKIA	N95
NOKIA	N95 3G
NOKIA	N95 8 GB
NOKIA	N96
NOKIA	N97
NOKIA	X2-01
NOKIA	X3-00
NOKIA	X3-02
NOKIA	X6-00
Observa Telecom	GW08-3G^GW08-3G
OWN	F1009^F1009
OWN	F1010
OWN	F1020
OWN	F1021
OWN	F1022^F1022
OWN	F1030
OWN	F1035^NL01D-Aponi
OWN	F2020
OWN	FTU152B^Smart HD
OWN	FTU161G^Fun +
OWN	FUN - S1
OWN	I62S OWN-Selfie
OWN	ONE^ONE
OWN	S3000^S3000
OWN	S3010
OWN	S3015
OWN	S3030
OWN	S4010
OWN	S4025
OWN	S4030
OWN	S4035 3G

Marca	Modelo
OWN	S4035 4G
OWN	S4040
OWN	S5010
OWN	S5030
OWN	S508D ^Style
OWN	S509D ^Smart
Palm	750
Palm	Centro
Palm	TREO 650
Palm	TREO 750
Panasonic	EB-A102
Panasonic	EB-X300
Panasonic	VS3
Pantech	PG-3000
Qtek	8015
Sagem	202
Sagem	MY301
Sagem	my-X5
Samsung	B3410
Samsung	C3510
Samsung	C5212
Samsung	CORE PRIME LTE - SM-G360GY
Samsung	E2120
Samsung	E256
Samsung	E356
Samsung	Galaxy A5 - SM-A500Y
Samsung	GALAXY ACE 4 - SM-G316MY
Samsung	GALAXY ACE 4 - SM-G316ML
Samsung	Galaxy ACE 4 Neo - SM-G316U
Samsung	Galaxy Grand Prime LTE - SM-G530MU
Samsung	GRAND Neo Plus - GT-I9060M
Samsung	GRAND PRIME LTE - SM-G530M
Samsung	GT I8260L (Galaxy Core)
Samsung	GT-B3310
Samsung	GT-C3300i
Samsung	GT-C3300K
Samsung	GT-C3510
Samsung	GT-C5510
Samsung	GT-C6112
Samsung	GT-E1086L
Samsung	GT-E2120
Samsung	GT-E3210L
Samsung	GT-I5500 (Galaxy 5)
Samsung	GT-I5700
Samsung	GT-i5800L
Samsung	GT-I6230

Marca	Modelo
Samsung	GT-i8000L
Samsung	GT-I8190 (Galaxy SIII Mini)
Samsung	GT-I8260E (Galaxy Core E)
Samsung	GT-i8510 (Innov 8)
Samsung	GT-I8550E (Galaxy Win E)
Samsung	GT-I8550L (Galaxy Win)
Samsung	GT-i9000B (Galaxy S)
Samsung	GT-i9003L (Galaxy SL)
Samsung	GT-I9060L Galaxy Grand Neo
Samsung	GT-i9063T GALAXY GRAND Neo
Samsung	GT-I9070 (Galaxy Advance)
Samsung	GT-I9080E (Galaxy Grand E)
Samsung	GT-I9080L (Galaxy Grand)
Samsung	GT-i9100 (Galaxy SII)
Samsung	GT-I9195 (Galaxy SIV Mini)
Samsung	GT-i9250 (Galaxy Nexus)
Samsung	GT-I9300 (Galaxy SIII)
Samsung	GT-I9300I Galaxy SIII Neo
Samsung	GT-I9505 (Galaxy SIV)
Samsung	GT-I9515L Glxy S4
Samsung	GT-M2520
Samsung	GT-M3710
Samsung	GT-M8800
Samsung	GT-N7000 (Galaxy Note)
Samsung	GT-N7100 (Galaxy Note II)
Samsung	GT-S3600
Samsung	GT-S3650
Samsung	GT-S3770L
Samsung	GT-S3770M
Samsung	GT-S5220
Samsung	GT-S5230
Samsung	GT-S5260
Samsung	GT-S5310E (Galaxy Pocket Neo)
Samsung	GT-S5310L
Samsung	GT-S5310M
Samsung	GT-S5310N
Samsung	GT-S5350L
Samsung	GT-S5360 (Galaxy Y)
Samsung	GT-S5560
Samsung	GT-S5560i
Samsung	GT-S5570 (Galaxy Mini)
Samsung	GT-S5600
Samsung	GT-S5620
Samsung	GT-S5830L (Galaxy Ace)
Samsung	GT-S5830M (Galaxy Ace)
Samsung	GT-S6010L (Galaxy Music)

Marca	Modelo
Samsung	GT-S6310L (Galaxy Young)
Samsung	GT-S6500L (Galaxy Mini II)
Samsung	GT-S6790E (Galaxy FAME Lite)
Samsung	GT-S6810E (Galaxy Fame)
Samsung	GT-S7390E (Trend Lite)
Samsung	GT-S7500L (Galaxy Ace Plus)
Samsung	GT-S7550 (Blue Earth)
Samsung	GT-S7580E (Trend Plus)
Samsung	GT-S8500L (Wave)
Samsung	i5500L (Galaxy 5)
Samsung	i6220 (Star TV)
Samsung	I8910 (Omnia HD)
Samsung	M2710
Samsung	M7600
Samsung	M8800
Samsung	R225
Samsung	S8000
Samsung	SGH-A177
Samsung	SGH-A516
Samsung	SGH-A706
Samsung	SGH-A736
Samsung	SGH-C126
Samsung	SGH-C207L
Samsung	SGH-C216
Samsung	SGH-C260
Samsung	SGH-C266
Samsung	SGH-C275
Samsung	SGH-C406
Samsung	SGH-C425
Samsung	SGH-C506
Samsung	SGH-C510
Samsung	SGH-C516
Samsung	SGH-D406
Samsung	SGH-D807
Samsung	SGH-D900
Samsung	SGH-E215L
Samsung	SGH-E251L
Samsung	SGH-E256
Samsung	SGH-E316
Samsung	SGH-E356
Samsung	SGH-E376
Samsung	SGH-E496
Samsung	SGH-E608
Samsung	SGH-E630
Samsung	SGH-E720
Samsung	SGH-E736

Marca	Modelo
Samsung	SGH-E786
Samsung	SGH-E906
Samsung	SGH-F250L
Samsung	SGH-F275
Samsung	SGH-F480
Samsung	SGH-F700
Samsung	SGH-I560
Samsung	SGH-I617
Samsung	SGH-i637
Samsung	SGH-i710
Samsung	SGH-I897
Samsung	SGH-i900L
Samsung	SGH-J160
Samsung	SGH-L760
Samsung	SGH-M110
Samsung	SGH-M310L
Samsung	SGH-M620
Samsung	SGH-R225
Samsung	SGH-T459
Samsung	SGH-T469
Samsung	SGH-t519
Samsung	SGH-T669
Samsung	SGH-T929
Samsung	SGH-T959
Samsung	SGH-U600
Samsung	SGH-U700
Samsung	SGH-X156
Samsung	SGH-X160
Samsung	SGH-X166
Samsung	SGH-X426
Samsung	SGH-X466
Samsung	SGH-X486
Samsung	SGH-X506
Samsung	SGH-X526
Samsung	SGH-X550
Samsung	SGH-X620
Samsung	SGH-X636
Samsung	SGH-X656
Samsung	SGH-X660
Samsung	SGH-X836
Samsung	SM-G110M ^POCKET 2
Samsung	SM-G313M ^ Glxy Ace 4 Lite
Samsung	SM-G313ML ^ Galaxy Ace 4 Lite
Samsung	SM-G313MY ^GALAXY ACE 4
Samsung	SM-G313U ^ Galaxy Ace 4
Samsung	SM-G350L Galaxy Core Plus

Marca	Modelo
Samsung	SM-G355H Galaxy Core II
Samsung	SM-G355M Galaxy Core II
Samsung	SM-G530H ^GRAND PRIME 3G
Samsung	SM-G531H ^Galaxy Grand Prime VE
Samsung	SM-G850Y Galaxy Alpha
Samsung	SM-G900M (Galaxy S5)
Samsung	SM-G920I - Galaxy S6
Samsung	SM-G925I- Galaxy S6 EDGE
Samsung	SM-G930F^GALAXY S7
Samsung	SM-G935F^GALAXY S7 EDGE
Samsung	SM-J110M ^J1 Ace
Samsung	SM-J111M^GALAXY J1 ACE VE
Samsung	SM-J200M^GALAXY J2
Samsung	SM-J320M^GALAXY J3 2016
Samsung	SM-J700M ^Galaxy J7
Samsung	SM-N7505L (Galaxy Note 3 Neo LTE)
Samsung	SM-N9005 (Note III)
Samsung	SM-N910U Galaxy Note 4
Samsung	T809
Siemens	A56
Siemens	A65
Siemens	A70
Siemens	AX72
Siemens	AX75
Siemens	C65
Siemens	C72
Siemens	C75
Siemens	CF75
Siemens	CX65
Siemens	CX75
Siemens	MC60
Siemens	SL75
Siemens	SX1
SONY	C1504 (Xperia E)
SONY	C1904 (Xperia M)
SONY	C2104 (Xperia L)
SONY	C5302 (Xperia SP)
SONY	C5502 (Xperia ZR)
SONY	C6502 (Xperia ZL)
SONY	C6906 (Xperia Z1)
SONY	D2004 (Xperia E1)
SONY	D2306 (Xperia M2)
SONY	D2533 (Xperia C3)
SONY	D6503 (Xperia Z2)
SONY	E6553 ^Xperia Z3+
SONY	E6853 ^Xperia Z5 Premium

Marca	Modelo
SONY	Xperia C5 Ultra - E5506
SONY	Xperia E4 E2104
SONY	Xperia E4g - E2053
SONY	Xperia M4 Aqua - E2306
SONY	Xperia M5 - E5606
SONY	XPERIA Z3 - D6653
Sony Ericsson	C510a
Sony Ericsson	C902
Sony Ericsson	C903a
Sony Ericsson	C905a
Sony Ericsson	CK13i (Mugua)
Sony Ericsson	CK15a (TXT Pro)
Sony Ericsson	E10 (X10 Mini)
Sony Ericsson	E15a (X8)
Sony Ericsson	F305
Sony Ericsson	G705
Sony Ericsson	J105a
Sony Ericsson	J108a
Sony Ericsson	J300
Sony Ericsson	K200
Sony Ericsson	K300
Sony Ericsson	K300i
Sony Ericsson	K310i
Sony Ericsson	K330a
Sony Ericsson	K510a
Sony Ericsson	K550
Sony Ericsson	K550i
Sony Ericsson	K700i
Sony Ericsson	K750i
Sony Ericsson	K790i
Sony Ericsson	K810i
Sony Ericsson	LT15a (Xperia Arc)
Sony Ericsson	LT18a (Xperia Arc S)
Sony Ericsson	LT26i (Xperia S)
Sony Ericsson	LT30p (Xperia T)
Sony Ericsson	M600
Sony Ericsson	MK16a (Xperia Pro)
Sony Ericsson	MT11a (Xperia Neo V)
Sony Ericsson	R300
Sony Ericsson	R800a (Xperia Play)
Sony Ericsson	S500i
Sony Ericsson	SK17a (Xperia Mini Pro)
Sony Ericsson	ST17a (Xperia Active)
Sony Ericsson	ST18a (Xperia Ray)
Sony Ericsson	ST21a (Xperia Tipo)
Sony Ericsson	ST23a (Xperia Miro)

Marca	Modelo
Sony Ericsson	ST25a (Xperia U)
Sony Ericsson	T226
Sony Ericsson	T226s
Sony Ericsson	T237
Sony Ericsson	T290
Sony Ericsson	T630
Sony Ericsson	T637
Sony Ericsson	T715a
Sony Ericsson	TM506
Sony Ericsson	U10
Sony Ericsson	U1a
Sony Ericsson	U20 (X10 Mini Pro)
Sony Ericsson	U5a (Vivaz)
Sony Ericsson	W100a
Sony Ericsson	W150a
Sony Ericsson	W20
Sony Ericsson	W200
Sony Ericsson	W205a
Sony Ericsson	W300
Sony Ericsson	W300i
Sony Ericsson	W302
Sony Ericsson	W380i
Sony Ericsson	W395
Sony Ericsson	W580i
Sony Ericsson	W610
Sony Ericsson	W610i
Sony Ericsson	W705a
Sony Ericsson	w710
Sony Ericsson	W710i
Sony Ericsson	W715
Sony Ericsson	W760i
Sony Ericsson	W800
Sony Ericsson	W810i
Sony Ericsson	W880
Sony Ericsson	W880i
Sony Ericsson	W890i
Sony Ericsson	W910i
Sony Ericsson	W980i
Sony Ericsson	W995
Sony Ericsson	W995a
Sony Ericsson	WT19a (Walkman)
Sony Ericsson	X10 mini
Sony Ericsson	X10 Mini Pro
Sony Ericsson	X10a
Sony Ericsson	X1a
Sony Ericsson	Z200

Marca	Modelo
Sony Ericsson	Z300
Sony Ericsson	Z310
Sony Ericsson	Z310i
Sony Ericsson	Z520
Sony Ericsson	Z550i
Sony Ericsson	Z750
Sony Ericsson	Z750i
Verykool	i315
Verykool	S732
Vodafone	ZTE - VF125
ZTE	BLADE X3- C370
ZTE	G R255
ZTE	N285
ZTE	R221
ZTE	R253
ZTE	S202
ZTE	S302
ZTE	S510
ZTE	v795
ZTE	V857
ZTE	V880E
ZTE	V887
ZTE	VF1230

Otros Terminales

Marca	Modelo
2N Telekomunikace	VoiceBlue MAX
Alcatel	L100I
Alcatel	L800
Alcatel	OT-Y859NC Link 4 II
Alcatel	P310A ONE TOUCH POP7
Alcatel	T70 EVO7
Alcatel	X200
Alcatel	X220F
Alcatel	X220Y
Alcatel	X500F
Alcatel	X500W
Amper	AMR-610^ROUTER 4G AMR-610
Apple	A1674 ^iPad Pro 9 7
Apple	iPad
Apple	iPad 2
Apple	iPad Air
Apple	iPad Air 2

Marca	Modelo
Apple	Ipad Air 5
Apple	Ipad Mini
Apple	Ipad mini 2
Apple	iPad Mini 3
Apple	iPad Mini 4
Apple	Ipad Pro
AUFBAU	V900
BandRich	R558E
CalAmp	LMU2000
CalAmp	LMU2720 - LMU27H200-G1000
CalAmp	LMU-3030
CalAmp	LMU800 - LMU08H200-G1000
CalAmp	QUBE 300
CalAmp	Qube 300 HSPA
Cellocator	CELLOCANIQ 50
Cellocator	CR - CR300 3G
Cisco	C819HG 7-K9
Cisco	C881G 7-K9
DCT	Antares GPS
Digi	Telit HE910-D ^Router3G
D-Link	DIR-412
D-Link	DIR-455
D-Link	DIR-457U
D-Link	DWM-156
D-Link	DWM-156_A2
D-Link	DWR-510
D-Link	DWR-530
DSC	GS3055-IG
DSC	GS3125
DSC	PC1616
DSC	TL2603G/3G2060
Eltek	L3220-E1
Eltek	L3310-E1
Enfora	GSM1308
Enfora	GSM1318-50
Enfora	GSM2228
Ericsson	F3507g
Giant	D301
Huawei	B260
Huawei	B310s-518
Huawei	B593s-516
Huawei	B683
Huawei	B68L
Huawei	E173u
Huawei	E173u-81
Huawei	E1756C

Marca	Modelo
Huawei	E176
Huawei	E182E
Huawei	E226
Huawei	E303s-63
Huawei	E3131i-81
Huawei	E3251s-81
Huawei	E3276s-151
Huawei	E3372h-510
Huawei	E353s-81
Huawei	E355s-6
Huawei	E367
Huawei	E369
Huawei	E372
Huawei	E5220s-81
Huawei	E5377Bs-508
Huawei	E5573s-508
Huawei	E5776s-32
Huawei	E5836
Huawei	E586Bs-6
Huawei	E660
Huawei	E8231s-81
Montseny	LT6626 ^ Indoor LTE Wireless CPE
Motorola	MZ605 ^ XOOM
Navman Wireless	Qube3
Navman Wireless	Qube4
NOKIA	CS-18
Novatel Merlin	XU870
Novatel Wireless	MC545
Novatel Wireless	MT 4100 - UMT2203
QUECLINK	GV300
QUECLINK	GV55
Robustel	w800-plus
Samsung	GEAR S - SM-R750W
Samsung	GT-P1000L (Galaxy Tab)
Samsung	GT-P3100 (Galaxy Tab 2 7.0)
Samsung	GT-P5100 (Galaxy Tab 10.1)
Samsung	GT-P6200L (Galaxy Tab 7.0 Plus)
Samsung	GT-P7500 (Galaxy Tab 10.1 3G)
Samsung	SM-T211 Galaxy Tab 3
Samsung	SM-T239M Galaxy Tab 4 VE
Sierra	AC875
Sierra	AC875U
Sony Ericsson	GC75
Sony Ericsson	GC79
Sony Ericsson	GC82
Sony Ericsson	GC85

Marca	Modelo
Sony Ericsson	GC89
Sony Ericsson	MD300
Spetrotec	I-WATCHER AVL^
Spetrotec	I-WATCHER CANBUS^CAN
Suntech	ST300KE^ST300KE
Suntech	ST340LC
Suntech	ST600R
SYSTECH	CAREU UCAN
TELIT	GE864-QUAD
ViewSonic	ViewPad 7
Visonic	POWERMASTER360^POWERMASTER360
ZTE	MF193
ZTE	MF253
ZTE	MF25A
ZTE	MF29
ZTE	MF613
ZTE	MF622
ZTE	MF631
ZTE	MF636
ZTE	MF636 plus
ZTE	MF645
ZTE	MF660
ZTE	MF668
ZTE	MF668a
ZTE	MF669
ZTE	MF680
ZTE	MF730M
Zyxel	WAH1005